SONY 3-758-049-21

FM/AM Clock Radio

ICF-C740

Operating Instructions

DREAM MACHINE

Sony Corporation © 1994 Printed in Malaysia

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.


CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL

This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure tha may be of sufficient magnitude to constitut a risk of electric shock to persons.

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

* The graphical symbols are on the rear enclosure.

Before You Begin

Thank you for choosing the Sony Dream Machine*! The Dream Machine will give you many hours of reliable service and listening pleasure.
Before operating the Dream Machine, please read these instructions thoroughly and retain them for future reference.

*Dream Machine is a trademark of Sony corporation.

Features

- Large easy to read display
- Dual alarm
- Date display
- Display with adjustable brightness
- Forward/reverse time setting
- Full power backup to keep the clock and the alarm (radio and buzzer) during a power interruption with a 6F22 battery (not supplied) installed

Installing the Battery

To keep good time, your Dream Machine needs one 6F22 battery (not supplied), in addition to house current. The battery keeps the clock operating in the event of a power interruption. Before setting the time on your Dream Machine, open the lid at the bottom of the unit, install the battery with correct polarity and then close the lid.

- After a power interruption, the displayed time may not be always correct. (It may gain or lose about 10 minutes per hour.)

Knowing When To Replace the Battery

- To check battery power, unplug the power cord from the wall outlet and plug it in again after a few minutes. If the displayed time is incorrect, replace the battery with a new one.

SONY®

PERSONAL/PORTABLE AUDIO PRODUCTS

LIMITED WARRANTY

SONY ELECTRONICS INC ("SONY") warrants this product against defects in material or workmanship, as follows:

For a period of 1 year from the date of retail purchase, SONY shall at its sole and absolute option either repair the defective product at no charge or replace the defective product with the same model or its equivalent model at no charge through a SONY SERVICE CENTER.

To obtain warranty service, you must take the product, or deliver the product prepaid, to one of the SONY SERVICE CENTERS located in the United States.

Proof of purchase in the form of a bill of sale or receipted invoice, which indicates that the product is within the warranty period, must be presented to obtain warranty service. SONY suggests that the purchaser retain the dealer's dated bill of sale as evidence of the date of retail purchase.

This warranty does not cover cosmetic damage, and damage to any part of the product, including the antenna, which results from acts of God, accident, misuse, abuse, improper maintenance, or connection to an improper voltage supply.

This warranty is valid only if the serial number appears on the product. This warranty is valid only in the United States of America.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SONY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. In addition, if you enter into a service contract with the Sony Partnership SM within 90 days of the date of sale, the limitation on how long an implied warranty lasts does not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Please refer to the list of SONY SERVICE CENTERS on the reverse side for the SONY SERVICE CENTER nearest you.

For your convenience, Sony Electronics Inc has established the Customer Information Center to supply you with product or service information.

SONY CUSTOMER INFORMATION CENTER
201-930-SONY (7669)
714-821-SONY (7669)
708-250-SONY (7669)

or write to:

SONY CUSTOMER INFORMATION CENTER
Sony Drive, Mail Drop #T1-11
Park Ridge, New Jersey 07656

SONY ELECTRONICS INC
Sony Drive, Park Ridge, New Jersey 07656

To obtain warranty service, please take the product, or deliver the product prepaid, to one of the following Sony Service Centers located around the United States.

All of the following items must be included when the product is shipped prepaid to the SONY SERVICE CENTER.

—Name, address and a phone number where you may be reached during the day.
—A copy of proof of purchase, as evidence that the product is within the warranty period.
—Brief description of the product defect.
—All supplied accessories with the product.

Sony Service Centers

Arizona

Phoenix
2240 North Scottsdale Road
Tempe, AZ 85281
(602) 949-7669

California

Burbank (Los Angeles area)
4100 Riverside Drive, Suite A
Burbank, CA 91505
(818) 842-7669

Costa Mesa (Orange County area)
2729 Bristol Street South
Costa Mesa, CA 92626
(714) 549-4833

San Bruno (San Francisco area)
751 Camino Plaza
San Bruno, CA 94066
(415) 871-2810

San Diego
8975 Complex Drive
San Diego, CA 92123
(619) 279-2724

San Jose
1359 Old Oakland Road
San Jose, CA 95112
(408) 280-7669

Colorado

Denver
Havana Place Center
10740 East Iliff Avenue
Aurora, CO 80014
(303) 755-7669

Florida

Fort Lauderdale
2850 North 28th Terrace
Hollywood, FL 33020
(305) 920-5600

Georgia

Atlanta
120 Interstate North Parkway East
Suite 410
Atlanta, GA 30339
(404) 953-5871

Hawaii

Honolulu
950 Mapunapuna Street
Honolulu, HI 96819
(808) 834-6622

Illinois

Chicago
1730 West Fullerton, Suite 4
Riverpoint Shopping Center
Chicago, IL 60614
(312) 929-8585

Niles (Chicago N.W.)
7540 North Caldwell Avenue
Niles, IL 60648
(708) 647-2400

Westmont (Chicago S.W.)
6036-38 South Cass Avenue
Westmont, IL 60559
(708) 969-0049

Kansas

Kansas City
11712 West 95th Street
Overland Park
KS 66214
(913) 888 2622

Maryland (Washington D.C.)

Washington D.C.
5300 Sunnyside Avenue
Beltsville, MD 20705
(301) 595-1818

Massachusetts

Boston
390 University Avenue
128 Westwood Industrial Center
Westwood, MA 02090
(617) 329 5130

Michigan

Detroit
43304 Eleven Mile Road
Novi, MI 48050
(313) 344-4044

Minnesota

Minneapolis
4300 W. 36 1/2 Street
St. Louis Park, MN 55416
(612) 920-8000

Missouri

St. Louis
12462-D Natural Bridge Road
Bridgeton, MO 63044
(314) 291-2201

New Jersey

Mahwah (N.Y. Metropolitan Area)
386 Route 17 South
Mahwah, NJ 07430
(201) 529-1655

Union
Bradlees Shopping Center
US Highway 22 At Morris Avenue
Union, NJ 07083
(201) 687-5555

Ohio

Cleveland
6370 York Road
Parma Heights, OH 44130
(216) 845-7669

Pennsylvania

Philadelphia
651 Park Avenue
King of Prussia, PA 19406
(215) 768-8850

Pittsburgh
Wexford Plaza
10610 Perry Highway (Rt. 19N)
Wexford, PA 15090
(412) 935-8466

Texas

Dallas
401 Preston Valley Shopping Center
Dallas, TX 75230
(214) 661 3537

Houston
7639 Westheimer
Houston, TX 77063
(713) 783 8761

Washington

Seattle
835 Fidalgo
Seattle, WA 98108
(206) 762-6500


CLOCK
A
ALARM
RADIO
BUZZER
B
TIME SET
SNOOZE/DATE/SLEEP OFF
ALARM RESET/OFF
SLEEP
OFF
RADIO
ON
BRIGHT
LOW
HIGH
VOLUME
BAND
AM
FM
TUNING

Setting the Clock and the Date

Setting the Clock

1. Plug in the unit.
   The display will flash "AM 12:00".
2. While holding down **CLOCK**, press either **+** or **–** under **TIME SET** till the correct time appears in the display. When you release **CLOCK**, the clock begins to operate.

- To set the current time rapidly, keep pressing the + or – button while holding down **CLOCK**.

Setting the Date

1. While holding down **SNOOZE/DATE/SLEEP OFF**, press either **+** or **–** under **TIME SET** till the correct date appears in the display. Then, release **SNOOZE/DATE/SLEEP OFF**.

- To display the date, press **SNOOZE/DATE/SLEEP OFF**. The display returns to the current time when you release **SNOOZE/DATE/SLEEP OFF**.

Changing the Brightness of the Display Window

To change the brightness of the display window, slide **BRIGHT** (brightness) to **HIGH** or **LOW** on the rear exterior of the unit.

Playing the Radio

1. Press **RADIO ON/SLEEP** to turn on the radio and adjust **VOLUME**.
2. Select **FM** or **AM** , and tune in a station using the **TUNING** dial.

- To turn off the radio, press **RADIO OFF/ALARM RESET/OFF**.
- To improve radio reception
  FM: Since the antenna is encased in the AC power cord, extend the cord to improve FM reception.
  AM: Rotate the unit horizontally for optimum reception. A ferrite bar antenna is built into the unit.

Setting the Alarm

To set the radio alarm, first tune in a station and adjust the volume.

1. While holding down the **ALARM A** or **B** button (for example, **A** for the radio or **B** for the buzzer), press either **+** or **–** under **TIME SET** till the desired time appears in the display. When you release **ALARM A** or **B** , the **ALARM A** or **B** indicator and ":" stop flashing and light up, and the current time appears in the display.
2. Set the **ALARM A** selector (for radio) to **RADIO** or **ALARM B** selector (for buzzer) to **BUZZER**. The alarm will come on at the preset time and automatically turn itself off after 59 minutes.

- If you set **ALARM A** and **ALARM B** at the same desired time, only **ALARM A** will work.
- To shut off the alarm, press **RADIO OFF/ALARM RESET/OFF**. The alarm will come on at the preset time the next day.
- To cancel either alarm, while holding down the **ALARM A** or **ALARM B** button, press **RADIO OFF/ALARM RESET/OFF**.
- To doze for a few more minutes, press **SNOOZE/DATE/SLEEP OFF**. The alarm will shut off, but will come on again after about 6 minutes. You can repeat this process as many times as you like.
- To adjust the radio alarm volume, turn **VOLUME**.
- To check the preset time, press **ALARM A** or **B**.

Setting the Sleep Timer

Enjoy falling asleep to the radio using the built-in sleep timer that shuts off the radio automatically at a preset time.

1. Press **RADIO ON/SLEEP**.
   The radio turns on. It will go off after the preset time has passed. You can set the sleep timer of 90, 60, 45, 30 or 15 minutes.
   Every push changes the display as follows.

Current time On → 90 → 60
↑ 15 ← 30 ← 45 ←┘

The radio will play for the time you set, then shut off.

- To turn off the radio before the preset time, press **SNOOZE/DATE/SLEEP OFF**.

Precautions

- Operate the unit on the power sources specified in "Specifications".
- To disconnect the power cord, pull it out by the plug, not the cord.
- Do not place the unit on the surfaces (rugs, blankets. etc.) or near materials (curtains draperies) that block the ventilation holes
- Should anything solid object or liquid fall into the unit, disconnect the AC power cord and have the unit check by qualified personnel before operating it any further.
- To clean the casing, use a soft cloth dampened with a mild detergent solution.

Battery Warning

When the unit will be left unplugged for a long time, remove the battery to avoid undue battery discharge and damage to the unit from battery leakage.

If you have any questions or problems concerning your unit, please consult your nearest Sony dealer.

Specifications

Frequency range: FM: 87.6 - 108 MHz
AM: 530 - 1,610 kHz
Speaker: Approx. 6.6 cm (2 5/8 inches) dia.
Power output: 120 mW (at 10% harmonic distortion)
Power requirements: 120 V AC, 60Hz
For power backup: 9 V DC, one 6F22 battery
Battery life: Approx. 35 hours using the Sony S-006P(U) battery
Dimensions: Approx. 221 × 99 × 117 mm (w/h/d) (8 3/4 × 4 × 4 3/4 inches) not incl. projecting parts and controls
Mass: Approx. 740 g (1 lb 10 oz) not incl. battery

Design and specifications are subject to change without notice.